LOFTER®
be inspired

Instruction Manual

Coffee Grinder
MODEL NO: HY-1422



Caution

Read all the instructions carefully before using this product.

- This appliance was constructed to process normal household quantities.
- Before operating check whether your voltage corresponds to the voltage printed on the bottom of the unit.
- To protect against risk of electrical shock do not put the unit in water or other liquid.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Never remove the transparent lid before the blades have stopped rotating.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let cord hang over the edge of table or counter.
- Check hopper(bowl) for the presence of foreign objects before using.

Accessories, other than those supplied with the appliance, shall include instructions for their safe use. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Description

1.Cover	6.Button
2.Upper Body	7.Button Decorative Ring
3.Clutch	8.Knife
4.SUS Decorative Ring	9.Container
5.Body	



Packing List

1*Grinding machine
1*2-Blade cup
1*4-Blade cup
1*Working lid
2*Sealing covers
1*Clean brush
1* Instruction manual

Application Situation

Our coffee grinder is equipped with 2 grinding cups for different conditions.

2-Blade cup (dry grinding)	4-Blade cup (wet grinding)
coffee bean	spices
grains	jam
nuts	vegetables

To Use

Take care not to overload the unit. Do not fill coffee beans beyond the brim of the unit. To start the coffee grinder, replace the transparent lid onto the motor part, and depress the on/off switch. To stop it, simply release the on/off switch.

During grinding, if coffee powder starts collecting on the edge of the appliance where it is out of the reach of the blade, shake the appliance gently so that coffee powder falls back inside.

The coffee grinding grade is influenced by the quantity of coffee beans added and the length of grinding.

The longer the coffee beans are ground, the finer the coffee powder. Shorter grinding results in coarser coffee powder.

Grinding grade	Gram	Time
Coarse	70g	30s
Medium	50g	30s
Fine	30g	30s

As a general guide, the chart above provides suggested bean quantities and recommends grinding time:

It is recommended not to continue grinding for more than 45 seconds. Longer operation does not result in a finer grind but simply overheats the coffee resulting in loss of aroma. You will soon find your desired consistency of grind.

After grinding your coffee, take off the transparent lid from the motor part n and pour out the coffee grounds. For additional accuracy, use the calibrations on the side of the transparent lid. Note: For optimal flavors, it is recommended to grind coffee beans immediately before brewing.

If grinding is excessive, use the Sealing cover to cover it for better storage.

Cleaning

Always unplug the unit before cleaning. The transparent lid can be washed by hand, do not clean it in the dishwasher. The grinding area in the motor part should be cleaned with a small brush. Wipe the motor part with a damp cloth only.

Electrical Specifications

Voltage: 120V~ Frequency: 60Hz Wattage: 200W

About LOFTER

Found in 2012, LOFTER is a professional supplier of consumer electronic products and home appliance, especially specialized in lighting and kitchen appliances. Our mission is to provide innovative and high quality products so our clients can get access to high tech and have a simpler and better life.

Warranty

Thanks for your purchase!

If the product arrived defective or doesn't meet your satisfaction, please feel free to let us know.

We will try our best to make you have a happy shopping.

24 hours customer service

Customer Service Email: service@belofter.com

Website: www.belofter.com